

Ovation 1-2 Basic Installation.

Always **DISCONNECT** Electric Power and Fuel Lines.

Kit-W02-6000 (set of 2)
N603 K-C-[color] operating keys



1. Open the door and remove the old lock.
Hold the mounting plate template as shown in the “sweet spot” and mark a pilot hole.



2. Drill a 3/16” pilot hole.



3. Remove the mounting plate.
Drill 3/4” hole from front through the pilot hole.



4. Reverse the mounting plate template to line up with the 3/4” hole.



5. Insert the lock through the door and plate, and slide on the washer and gasket.
Secure the lock with the cylinder nut.



6. Attach the cam to the lock assembly with the locking cam nut as shown. The hook should face downward with top edge level to the ground.



7. Close the door. Open the other door. Mark the spot below the arc of the cam as shown in the picture.



8. Drill a 1/4" inch hole through the spot from the inside.



9. Insert the locking screw and secure it with a hex nut. Bend the cam slightly to the front or back to ensure a tight fit over the screw when closed.



10. Close the door and test for a tight fit, bending the cam if necessary.



Reconnect the power.

Reconnect the fuel line.

Questions or problems?

Call 800-422-2866 or 951-277-5170.

between 7:00am and 7:00pm

Monday through Friday Pacific Time.